



MaxRanger4KTM Solar Wireless Security System

Power Hub & Swann Security Quick Start Guide



1 Prepare your Hardware

Take the MaxRanger4K™ antennas from the box and screw one to each Camera and to your MaxRanger4K™ Power Hub. Do them up firmly to ensure a good connection but do not over-tighten. Point them straight up or straight down for the best signal.

Open the silicone flap at the rear of each of your MaxRanger4K™ Cameras and move the power switch to the ON position. After a short time, you should hear a beep-beep sound to confirm they have powered up successfully.



Ensure that when closing the silicone flap, it fits snugly against the camera casing to prevent moisture from getting inside.





Locate the On-Off switch and turn to ON.

2 Connect your Power Hub to your Home Network

1. Connect the network cable from the box to the Network port on your Power Hub.
2. Connect the other end to a spare port on your router or network device.
3. First, connect the power adapter cord to the power input on your Power Hub. Then, plug the adapter into a power outlet and switch it on if necessary.

Solid green and flashing yellow on Network port: [Network communication](#). Solid red on Power Hub: [Successful network connection](#).

No power outlet? Remove the blue label from the battery terminals, then insert the battery into the charging bay to provide power temporarily for the Power Hub setup.



Connect power adapter after setup when using battery.

3 Download the Swann Security App




1. Scan the QR Code.
2. Follow the on-screen instructions to install.
3. Locate the app and tap to run.



1. Scan the QR Code.
2. Follow the on-screen instructions to install.
3. Locate the app and tap to run.




4 Register your Account



The screenshot shows the Swann Security app's registration interface. At the top, the status bar displays the time 11:49 and signal strength. The app's logo, 'swann', is centered in white on a blue background. Below the logo, the text 'Welcome to Swann' is displayed. There are two input fields: 'Your email address' and 'Your password'. The password field has an eye icon to its right. A link 'Forgot Password?' is located below the password field. A grey 'Sign In' button is positioned below the input fields. At the bottom, there is a link 'Not yet registered? Register' with a hand icon pointing to it. At the very bottom, there is a link 'Terms of Service | Privacy Policy'.

- 1.** If you don't already have a Swann Security app account, tap "Register".
- 2.** Enter your details and create a password. Using a minimum of six characters that must contain a mixture of numbers and letters.
- 3.** Input your address or tap "Use my current location".
- 4.** You will receive an email asking to verify your email address. Once verified, you will receive a welcome email confirming your registration. Please note: If you do not receive the email, check your junk or spam folder.
- 5.** You will be taken back to the sign-in page. Upon verification, enter your email address and account password, then tap "Sign In".


5 Pair your MaxRanger4K™ System



1. Ensure that your mobile device is connected to your home network and the internet.
2. Tap “Pair Device”, then tap “Start”.
3. From the Swann Security app, scan the QR code located on the bottom of your Power Hub as illustrated below.



6 Create a Password and Name your Device



11:52

< Scan QR code

MaxRanger4K™

Welcome to connecting your new recorder! To ensure your device's security, please create a unique password for it. Your password will help keep your recordings private and secure.

User name

admin

Create a password at least 6 characters

Confirm password

Link to Swann Account


Give your Power Hub a password. The password has to be a minimum of six characters, and it can contain a mixture of numbers and letters.

Please note: Keep your password secure for later access.

When finished, tap “Link to Swann Account”.

Next, give your device a name that is familiar or select a name from the list.

Tap on the place of purchase, then tap “Done” to finish.



11:53

Cancel Pair Device

MaxRanger4K™

Give your device a helpful name, for example, describing the location it's installed at


NVWMR4K

Some recommendations

- Front Door
- Back Door
- Garage
- Living Room
- Driveway
- Porch

Next


7 Sign Up for Optional Secure+ Plans



Join our Swann Secure+ Service Plans for peace of mind. Tap the “Blue Bar” to start your free trial or “Skip” to activate later (for Android users, tap the back arrow button).

On the next screen, tap “Live View” at the bottom of the app to view live video from your cameras in the app.

Temporarily remove the battery and restart the Power Hub (disconnect, then reconnect the power adapter) to complete the Startup Wizard.



8 Advanced Instruction Manuals

Scan this QR code to download the advanced instruction manual for your MaxRanger4K™ Power Hub.



Scan this QR code to download the advanced instruction manual for your MaxRanger4K™ cameras.



Helpdesk & Resources

Visit Swann Support Center at support.swann.com. You can register your product for dedicated customer support, download guides, find answers to commonly asked questions, and more.



Support Community



Customer Support



Product Manuals



Frequently Asked Questions



EXPQSGMR4KREV3E | © Swann 2024